



Mounting Suggestions for the Harley-Davidson® FX/FL Big Twin 1965-1984 Passenger Seat

Tools Required:
• Phillips Screwdriver

Hardware:
• Stock Rear Fender Screw



Baseplate Features:

Mustang passenger seats have two chrome tabs that align with mounting holes in the back of the solo. Chrome rear tab matches stock fender hole. The baseplate features elastic polyurethane rubber bumpers to protect the motorcycle and soften vibrations as well as carpet to protect the fender.

Stock One-Piece Seat Removal Steps

1. Remove rear fender screw located behind the passenger seat and set aside. The stock rear fender screw will be used to attach your new Mustang Passenger Seat.
2. Slide seat back and up.

Mounting of Mustang Passenger Seat

1. Remove two screws from back of Mustang solo seat.
2. Align two chrome tabs located at the front of the passenger seat with holes in back of solo.
3. Screw rear seat and solo together.
4. Align chrome rear tab located at back of passenger seat with hole in fender.
5. Secure with stock fender screw to complete the installation process.

Enjoy the Comfort of your new Mustang Seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at <http://www.mustangseats.com>