



Mounting Suggestions: Harley-Davidson® Softail 2000-up Solo Seat

Baseplate Features:

All seats are built on 16 gauge formed steel baseplates. The baseplates have rubber supports at contact points. Mustang Softail solos have two removable side brackets that align with the large threaded holes in the softail frames. When the solo and pad are assembled, the side brackets on the solo can be removed and the seat mounted with just the single rear screw. Mustang pads are connected to the solo with two hidden screws. Harley-Davidson Softail rear seats do not directly fit to Mustang solos.



Removal of Stock Passenger Seat

1. Unscrew solo slotted side screws if stock seat is two-piece type.
2. Unscrew rear fender screw. NOTE: Spring loaded screws stay attached to brackets.
3. Slide seat back and up.
4. Remove the side mounting inserts in frame (one on each side) using a 3/4" wrench.

Mounting of Mustang Passenger Seat

1. Be sure that 7/16" (head) bolts that secure the side mounting brackets to the bottom of the Mustang solo seat are not loose.
2. Insert front seat mounting tab into the frame mount behind the fuel tank.
3. Align side brackets with large threaded holes in frame.
4. Secure side brackets with Mustang's chrome solo bolts part #78033 provided.

Hardware included: 2000-up solos are shipped complete with chrome side bolts.

Enjoy the Comfort of your new Mustang Seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at <http://www.mustangseats.com>