



# Mounting Suggestions for the Harley-Davidson® Softail Wide Tire (200 mm) FXST 2006-2009, FLSTF Fat Boy 2007-2009 & FLSTSB Cross Bones 2008-2009 Tank Bib

## Mounting of Mustang Tank Bib

1. Remove seat then with a 1/2" wrench, loosen the dash acorn nut and remove the lower panel screw.
2. Lift back of dash approximately 1/2", then slide panel down off of the two mounting tabs and out from under dash.
3. Lift end of dash up and slide bib under until the top 2 chrome studs are covered. Covering the top studs ensures that it will not slide out. Now tighten dash nut.
4. Wrap the bib's velcro ties around frame at base of tank.
5. Lower mounting screw is not needed but can be installed if desired.
6. Reinstall seat.

**Enjoy the custom look of your Mustang Tank Bib!**



Step 1



Step 2



Step 3



Step 4 & 5



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to [questions@mustangseats.com](mailto:questions@mustangseats.com) or visit our website at <http://www.mustangseats.com>