



Mounting Suggestions for the Harley-Davidson® Sportster 1979-2003 One-Piece Seat

Tools Required:
• Phillips Screwdriver

Hardware:
• Stock Rear Fender Screw
• Nylon Washer x1
(Included w/ 1996-03 Seat Only)

1979-81 XL, XLH and XLS Models



Baseplate Features:

The one-piece, 16 gauge steel baseplates are black epoxy powder coated on both sides for complete rust proofing. Carpet protects fender paint. Polyurethane bumpers are strategically located and riveted to the baseplate to prevent the baseplate from touching the frame and fender and to minimize vibration. The edges of all baseplates have a steel reinforced, impact absorbing vinyl edge trim to protect the seat cover. Exposed brackets are bright chrome plated.

1982-95 883, 1000, and 1200 XL Models



The nose tab on the baseplate for the 1982-95 883, 1000, and 1200 XL models is 1" further back than that on the 1979-81 baseplate.

The nose on the 1996-03 XL baseplate is shortened to allow room for the 3.3 gallon fuel tank and will also fit 1983-85 XLS Roadster models.

1996-03 XL and all models with a 3.3 Gallon Fuel Tank



Stock One-Piece Seat Removal Steps

1. Remove rear fender screw located behind the passenger seat and set aside. The stock rear fender screw will be used to attach your new Mustang One-Piece Seat.
2. Slide seat back and lift up.

These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at <http://www.mustangseats.com>

Stock Two-Piece Seat Removal Steps

1. Remove rear fender screw located behind the passenger seat and set aside. The stock rear fender screw will be used to attach your new Mustang One-Piece Seat.
2. Spread the foam between the solo and rear seat and loosen the solo mounting screw.
3. Pull rear seat back and up.
4. Remove rear fender screw located at the rear of the solo seat.
5. Slide the solo seat back and up.

Mounting of Mustang Seat

1. Engage nose bracket onto the welded frame tab.
2. A firm downward chop to the nose of the seat will push the seat closer to the fuel tank.
3. Align chrome rear tab with stock fender hole. ***Note: On 1996-03 model, use the supplied nylon washer between the chrome bracket and fender.***
4. Push the seat down and secure in place with stock fender screw to complete the installation process.

Enjoy the Comfort of your new Mustang Seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at <http://www.mustangseats.com>