



Mounting Suggestions: Kawasaki Vulcan 2000 Classic 2004-09 & LT 2006-09 Fender Bib

Tools Required:

- Metric Sockets
- Metric Allen Wrenches

Hardware:

- 6 mm Chrome Allen Bolts (Included)
- Chrome Washers(Included)

Mounting of Mustang Fender Bib

1. Remove rear seat and all its mounting hardware. Brackets are removed using a 10 mm socket.
2. Remove front seat using an 8 mm socket. It is a good idea to reinstall the two center bracket bolts back into the fender to plug the holes.
3. Lay bib on fender. Place solo over bib's front mounting holes then fasten to fender.
4. Align the fender bib's rear mounting holes with fender holes then fasten with supplied chrome 6 mm Allen bolts and chrome washers.

NOTE: Mustang recommends removal of fender bib before reinstalling rear seat. Mounting a rear seat over a fender bib can result in poor seat alignment or damage to the fender bib.

Enjoy the custom look of your new Mustang Fender Bib!



Step 1



Step 2



Step 4



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at <http://www.mustangseats.com>