



MOUNTING SUGGESTIONS

Harley-Davidson® FL Touring 1997-2008 Driver Backrest Kit

Hardware: 1/4"-20 x3/4" hex bolt and washer
1/4"-20 threaded clip
1997-1998 stock fender bolts or part 78028
1999-2008 stock fender nuts or part 78032

Tools needed: 7/16" open-end wrench
1999-2014 5/8 open-end wrench

Installation:

Note: This kit can only be used with Harley or Mustang one-piece seats that have the center opening to accept a backrest. This unit cannot be used with any solo seat or two-piece seat. Will not work with H-D Tallboy seat.

1. Remove the seat from the motorcycle.
2. Remove the bolts or nuts from the front fender mounts. These will be used to attach the backrest receiver.
3. Slip the supplied threaded clip over the pre-drilled frame member just above and behind the battery and align the holes.

4. Remove the pad and post assembly from the receiver base. Place the receiver base onto the motorcycle by aligning the felt-covered baseplate to the fender mounts, and the forward mount to the hole with the threaded clip. Secure the base with the two stock bolts or nuts (fender) and the supplied 1/4"-20x3/4" bolt and washer (frame).
5. Re-install the seat and secure with rear fender screw.
6. Insert the pad and post assembly through the seat opening and into the receiver base.



Adjustment:

The height of the post (up/down) is controlled by a spring-actuated plunger pin. The tension of this pin can be adjusted as follows: turn the set screw clockwise to increase tension and counterclockwise to decrease tension.

The tilt angle (front/back) is controlled with the 5/16"-24x5/8" knurled thumbscrew at the front of the post. Turn clockwise to tilt forward, and counterclockwise to tilt back.

These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 8:30 - 5:00 Eastern or send an e-mail to tech@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 79062, 79063 , 79065, 79067, 79068, 79072



Products made by Mustang Motorcycle Products, LLC are warranted for one year against defects in material and workmanship. Mustang must first be notified of any apparent defect. A return authorization will be issued. Carefully pack the product and return prepaid. Upon receipt, Mustang will make a fair, prompt decision regarding repair or replacement.

Incidental and consequential damages arising from or in connection with the installation or use of a Mustang product are not covered by this warranty. An original purchase receipt must be provided to obtain a warranty repair or replacement.