



## Mounting Suggestions: Honda VTX 1300 Retro, S & T and VTX 1800 Retro, S & T Fender Bib

### Mounting of Mustang Tank Bib

1. Remove seat.
2. Remove rear seat mounting bracket from fender.
3. Attach rear of fender bib with stock 6 mm screw.
4. Front of bib attaches to fender using supplied Velcro® tape.
5. Install solo. (Velcro® piece remaining on fender is hidden under solo when bib is removed.)



*NOTE: Mustang recommends removal of fender bib before reinstalling rear seat. Mounting a rear seat over a fender bib may result in damage to the bib, poor seat alignment or other problems.*

**Enjoy the custom look of your Mustang Fender Bib!**



**Plain**



**Studded**



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to [questions@mustangseats.com](mailto:questions@mustangseats.com) or visit our website at <http://www.mustangseats.com>