

MOUNTING SUGGESTIONS:

Honda VT750 ACE 1998-2003

Solo and Passenger Seat

Hardware: Solo seat: Passenger seat:

Stock rear bolt Stock rear bolt

White nylon washer White nylon washer

Tools needed: Metric wrenches

Removal of stock seat:

- 1. Remove the bolt from the back of the passenger seat and set aside. This bolt is used to mount your new Mustang seat.
- 2. Slide the passenger seat forward and tilt upward to remove it from the motorcycle.



3. Remove the bolt from the back of the solo, and slide the solo back to remove from the motorcycle.

Installation of Mustang seat:

- 1. Engage the solo's front bracket with the frame receiver under the tank, position a nylon washer between the rear bracket and the fender, and install the stock bolt at the rear of the solo.
- 2. Slide the passenger seat's front bracket forward to engage the rear solo bolt.
- 3. Position a nylon washer between the rear bracket and the fender and secure with the stock rear bolt.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 75000, 75001, 75003, 75004, 75005, 75006, 79150, 79151, 79153, 79154, 79155, 79156

You are cordially invited to Tour the Mustang Factory

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.